DPS500
Windows XP / Vista / 7
32-bit / 64-bit
Driver Installation Guide

PRADOTEC
Innovation for Tomorrow

DPS500 READER
DRIVER INSTALLATION GUIDE
User Manual

Document ID : Installation Guide
Revision: 1.1

Revision History

Revision	Date	Comment
1.0	08/04/2011	- First Issue
1.1	09/11/2012	- Update OCR Driver v2.1.6.1 - Update SCR Driver v2.0.0.9 - Apply new menu interface

Disclaimer

The information contained in this document is subject to changes without notice.

This document contains the proprietary information that is protected by copyright. All rights are reserved.

Microsoft ®, MS ®, MS-DOS ® and Windows ® are U.S. registered trademarks of Microsoft Corporation.

Pentium ® is a U.S. registered trademark of Intel Corporation.

Table of Contents

1 INTRODUCTION 5

2 DPS500 READER PCSC USB DRIVER INSTALLATION GUIDE 5

2.1 MICROSOFT WINDOWS 7 5
2.1.1 Install 32-BIT Driver 5
2.1.2 Install 64-BIT Driver 5
2.1.3 Uninstall 5
2.2 MICROSOFT WINDOWS VISTA 6
2.2.1 Install 32-BIT Driver 6
2.2.2 Install 64-BIT Driver 6
2.2.3 Uninstall 6
2.3 MICROSOFT WINDOWS XP 7
2.3.1 Install 32-BIT Driver 7
2.3.2 Install 64-BIT Driver 7
2.3.3 Uninstall 7

3 INSTALLING THE DEVICE 8

1 Introduction

This document describes the install/uninstall procedures for the **DPS500** Reader for Windows XP, Windows Vista and Windows 7 Operating Systems.

2 DPS500 Reader PCSC USB Driver Installation Guide

2.1 Microsoft Windows 7

Ensure that ***Administrative Rights*** privileges are granted.

2.1.1 Install 32-BIT Driver

1. Insert the Product CD into the CD-ROM Drive and allow the Driver Installer to start automatically. Otherwise, run the installer at ***<CD DRIVE>:\ autorun.exe***. Then select Install 32-bit package.

2. Should there be any incompatible system settings during the installation, select **"Reinstall using recommended settings"**. Microsoft Windows 7 will automatically rectify this.

3. Follow all the wizards until DPS500 Reader PCSC & OCR USB Driver has been successfully installed.

2.1.2 Install 64-BIT Driver

1. Insert the Product CD into the CD-ROM Drive and allow the Driver Installer to start automatically. Otherwise, run the installer at ***<CD DRIVE>:\ autorun.exe.*** Then select Install 64-bit package.

2. Should there be any incompatible system settings during the installation, select **"Reinstall using recommended settings"**. Microsoft Windows 7 will automatically rectify this.

3. Follow all the wizards until DPS500 Reader PCSC & OCR USB Driver has been successfully installed.

2.1.3 Uninstall

1. Unplug the DPS500 Reader Device from the computer.

2. Go to Control Panel -> Program and Features to remove the package

   For DPS500 Reader PCSC
   - ***Windows Driver Package – PRADOTEC Corp (DPS500 PC/SC)USB (11/06/2012, 2.0.0.9)***

   For DPS500 Reader OCR
   - ***GX Full Uninstaller – 64bit only***
   - ***32 bit GX Full Uninstaller – 32bit & 64bit***

2.2 Microsoft Windows VISTA

Ensure that ***Administrative Rights*** privileges are granted.

2.2.1 Install 32-BIT Driver

1. Insert the Product CD into the CD-ROM Drive and allow the Driver Installer to start automatically. Otherwise, run the installer at ***<CD DRIVE>:\ autorun.exe***. Then select Install 32-bit package.

2. Should there be any incompatible system settings during the installation, select **"Reinstall using recommended settings"**. Microsoft Windows Vista will automatically rectify this.

3. Follow all the wizards until DPS500 Reader PCSC & OCR USB Driver has been successfully.

2.2.2 Install 64-BIT Driver

1. Insert the Product CD into the CD-ROM Drive and allow the Driver Installer to start automatically. Otherwise, run the installer at ***<CD DRIVE>:\ autorun.exe***. Then select Install 64-bit package.

2. Should there be any incompatible system settings during the installation, select **"Reinstall using recommended settings"**. Microsoft Windows 7 will automatically rectify this.

3. Follow all the wizards until DPS500 Reader PCSC & OCR USB Driver has been successfully

2.2.3 Uninstall

1. Unplug the DPS500 Reader Device from the computer.

2. Go to Control Panel -> Program and Features to remove the package

   For DPS500 Reader PCSC
   - ***Windows Driver Package - PRADOTEC Corp (DPS500 PC/SC)USB (11/06/2012, 2.0.0.9)***

   For DPS500 Reader OCR
   - ***GX Full Uninstaller – 64bit only***
   - ***32 bit GX Full Uninstaller – 32bit & 64bit***

2.3 Microsoft Windows XP

Ensure that ***Administrative Rights*** privileges are granted.

2.3.1 Install 32-BIT Driver

1. Insert the Product CD into the CD-ROM Drive and allow the Driver Installer to start automatically. Otherwise, run the installer at ***<CD DRIVE>:\ autorun.exe***. Then select Install 32-bit package.

2. Follow the instructions on screen. Select ***"Continue Anyway"*** when unsigned Windows Logo driver is reported. (This will appear multiple times).

4. Follow all the wizards until DPS500 Reader PCSC & OCR USB Driver has been successfully

2.3.2 Install 64-BIT Driver

1. Insert the Product CD into the CD-ROM Drive and allow the Driver Installer to start automatically. Otherwise, run the installer at ***<CD DRIVE>:\ autorun.exe***. Then select Install 64-bit package.

2. Should there be any incompatible system settings during the installation, select **"Reinstall using recommended settings"**. Microsoft Windows 7 will automatically rectify this.

3. Follow all the wizards until DPS500 Reader PCSC & OCR USB Driver has been successfully .

2.3.3 Uninstall

1. Unplug the DPS500 Reader Device from the computer.

2. Go to Control Panel -> Add Remove Program to remove the package

   For DPS500 Reader PCSC
   - ***Windows Driver Package - PRADOTEC Corp (DPS500 PC/SC)USB (11/06/2012, 2.0.0.9)***

   For DPS500 Reader OCR
   - ***GX Full Uninstaller – 64bit only***
   - ***32 bit GX Full Uninstaller – 32bit & 64bit***

3 Installing the Device

1. Connect the DPS500 Reader to a PC USB Port.

2. **Windows XP:** Follow the pop up instructions on screen. Select ***"Install the software automatically"*** when asked. Select ***"Continue Anyway"***

3. **Windows 7/Vista:** Allow the device to install itself automatically.