BCR200DTP
Windows XP / Vista / 7
32-bit / 64-bit
Driver Installation Guide

Disclaimer

The information contained in this document is subject to changes without notice.

This document contains the proprietary information that is protected by copyright. All rights are reserved.

Microsoft ®, MS ®, MS-DOS ® and Windows ® are U.S. registered trademarks of Microsoft Corporation.

Pentium ® is a U.S. registered trademark of Intel Corporation.

Table of Contents

1 INTRODUCTION 4

2 MICROSOFT VISUAL C++ 2008 REDISTRIBUTABLE INSTALLATION GUIDE 5

2.1 MICROSOFT WINDOWS 7/WINDOWS VISTA/WINDOWS XP 5

2.1.1 Install 32-BIT and 64- BIT Microsoft Visual C++ 2008 Redistributable 5

3 BCR200DTP USB DRIVER INSTALLATION GUIDE 6

3.1 MICROSOFT WINDOWS 7 6

3.1.1 Install 32-BIT and 64- BIT Driver (offline installation) 6

3.1.2 Install 32-BIT and 64- BIT (online installation – Smartcard driver only) 6

3.1.3 Uninstall 7

3.2 MICROSOFT WINDOWS VISTA 8

3.2.1 Install 32-BIT and 64- BIT Driver (offline installation) 8

3.2.2 Install 32-BIT and 64- BIT (online installation – Smartcard driver only) 8

3.2.3 Uninstall 9

3.3 MICROSOFT WINDOWS XP 10

3.3.1 Install 32-BIT and 64- BIT Driver (offline installation) 10

3.3.2 Install 32-BIT and 64- BIT (online installation – Smartcard driver only) 10

3.3.3 Uninstall 11

1 Introduction

This document describes the install/uninstall procedures for the BCR200DTP for Windows XP, Windows Vista and Windows 7 Operating Systems.

There are two option of installation namely:

1- Online installation through Windows update (supported for **Smartcard Driver Only**)
Note: Windows update requires internet connection

2- Offline installation through Product CD

In order to complete the installation, users **must** use the product CD to install the Sagem Biometric (CBM) driver which is not available through Windows update.

2 Microsoft Visual C++ 2008 Redistributable Installation Guide

2.1 Microsoft Windows 7/Windows Vista/Windows XP

Ensure that ***Administrative Rights*** privileges are granted.

2.1.1 Install 32-BIT and 64- BIT Microsoft Visual C++ 2008 Redistributable

1. Insert the Product CD into the CD-ROM Drive and allow the Driver Installer to start automatically. Otherwise, run the installer at <***CD DRIVE>:\ autorun.exe***.

2. The installer will check on your computer whether had installed Microsoft Visual C++ 2008 Redistributable. If no, Microsoft Visual C++ 2008 Redistributable installers will pop-up automatically. The installer will depend on your computer operating system bit to pop-up the suitable Microsoft Visual C++ 2008 Redistributable installer.

3. Follow the wizard appear, until installation is completed.

4. When installation is completed, menu of Product CD will pop-up automatically.

3 BCR200DTP USB Driver Installation Guide

3.1 Microsoft Windows 7

3.1.1 Install 32-BIT and 64- BIT Driver (offline installation)

Ensure that ***Administrative Rights*** privileges are granted.

1. Insert the Product CD into the CD-ROM Drive and allow the Driver Installer to start automatically. Otherwise, run the installer at <***CD DRIVE>:\ autorun.exe***.

2. The installer will ask for uninstallation of the old version of this product before installation started. For those installed old version before, this step is recommended.

3. Follow the wizards until BCR200DTP Driver has been successfully installed.

3.1.2 Install 32-BIT and 64- BIT (online installation – Smartcard driver only)

- ***Please ensure your pc is connected to internet***

1. Plug in the BCR200DTP Reader Device

2. Windows will install the driver automatically through windows update

   Note:
   If having problem "No Driver Found", use the alternative method to get the driver installation accomplished.

Alternative method:

1. Plug in the BCR200DTP Reader Device

2. Go to Device manager search for BCR200DTP devices under **Other devices** tree.
   Start -> Computer ***(right click, select Manage)*** *-> Device Manager*

3. Then right click and select the "**Update Driver Software…"**

4. Once the wizards appeared, select the "**Search Automatically for the updated driver software"**

5. BCR200DTP PCSC USB Driver has been installed.

6. Find the newly enumerated devices in this format
   PRADOTEC BCR200DTP xxxxxxx (CT/CL/VS) 0x

7. Repeat step 3-5 until devices finished.

3.1.3 Uninstall

1. Unplug the BCR200DTP Reader Device from the computer.

2. Go to Control Panel -> Program and Features to remove the package

   For BCR200DTP Reader PCSC
   - ***Windows Driver Package - PRADOTEC Corp (BCR200DTP PC/SC) USB (07/30/2012, 1.7.1.1)***

   For SAGEM CBM
   - ***For 64 bit : Sagem MorphoSmart USB 64-bits Drivers***
   - ***For 32 bit: Sagem MorphoSmart USB Drivers***

3.2 Microsoft Windows VISTA

3.2.1 Install 32-BIT and 64- BIT Driver (offline installation)

Ensure that ***Administrative Rights*** privileges are granted.

1. Insert the Product CD into the CD-ROM Drive and allow the Driver Installer to start automatically. Otherwise, run the installer at <***CD DRIVE>:\ autorun.exe***.

2. The installer will ask for uninstallation of the old version of this product before installation started. For those installed old version before, this step is recommended.

3. Follow the wizards until BCR200DTP Driver has been successfully installed.

3.2.2 Install 32-BIT and 64- BIT (online installation – Smartcard driver only)

- ***Please ensure your pc is connected to internet***

1. Plug in the BCR200DTP Reader Device

2. Select the option "**Locate and Install driver software (recommended)**"

3. Windows will install the driver automatically through windows update

   Note:
   If having problem "No Driver Found", use the alternative method to get the driver installation accomplished.

Alternative method:

1. Plug in the BCR200DTP Reader Device

2. Go to Device manager search for BCR200DTP devices under **Other devices** tree.
   Start -> Computer ***(right click, select Manage)*** *-> Device Manager*

3. Then right click and select the "**Update Driver Software…"**

4. Once the wizards appeared, select the "**Search Automatically for the updated driver software"**

5. BCR200DTP PCSC USB Driver has been installed.

6. Find the newly enumerated devices in this format
   PRADOTEC BCR200DTP xxxxxxx (CT/CL/VS) 0x

7. Repeat step 3-5 until devices finished.

3.2.3 Uninstall

1. Unplug the BCR200DTP Reader Device from the computer.

2. Go to Control Panel -> Program and Features to remove the package

   For BCR200DTP Reader PCSC
   - ***Windows Driver Package - PRADOTEC Corp (BCR200DTP PC/SC)USB (07/30/2012, 1.7.1.1)***

   For SAGEM CBM
   - ***For 64 bit : Sagem MorphoSmart USB 64-bits Drivers***
   - ***For 32 bit: Sagem MorphoSmart USB Drivers***

3.3 Microsoft Windows XP

3.3.1 Install 32-BIT and 64- BIT Driver (offline installation)

Ensure that ***Administrative Rights*** privileges are granted.

1. Insert the Product CD into the CD-ROM Drive and allow the Driver Installer to start automatically. Otherwise, run the installer at <***CD DRIVE>:\ autorun.exe***.

2. The installer will ask for uninstallation of the old version of this product before installation started. For those installed old version before, this step is recommended.

3. Follow the wizards until BCR200DTP Driver has been successfully installed.

3.3.2 Install 32-BIT and 64- BIT (online installation – Smartcard driver only)

- ***Please ensure your pc is connected to internet***

1. Plug in the BCR200DTP Reader Device.

2. Once the wizards appeared, select the "**Yes, this time only".** Click next. This wizard is optional.

3. Then the second wizards select the "**Install the software automatically (Recommended)**" and click next. If another wizard come out just select "continuous anyway" until it is installed.

4. BCR200DTP PCSC USB Driver has been installed.

5. Find the newly enumerated devices in this format
   PRADOTEC BCR200DTP xxxxxxx (CT/CL/VS) 0x

7. Repeat step 2-4 until devices finished.

   Note :
   Alternative way, to get the wizards through device manager under **Other devices** tree.
   Start -> Computer **(right click, select Manage)** -> Device Manager
   Then right click and select the "**Update Driver Software…"**

3.3.3 Uninstall

1. Unplug the BCR200DTP Reader Device from the computer.

2. Go to Control Panel -> Add or Remove Program to remove the package

   For BCR200DTP Reader PCSC
   - ***Windows Driver Package - PRADOTEC Corp (BCR200DTP PC/SC)USB (07/30/2012, 1.7.1.1)***

   For SAGEM CBM
   - ***For 64 bit : Sagem MorphoSmart USB 64-bits Drivers***
   - ***For 32 bit: Sagem MorphoSmart USB Drivers***